

SPLIT :

CODES ON DISPLAY



DISPLAY	DESCRIPTION *
88--	StartUp message: Kit ON
Lb	Low Battery
bb	= Lb
E0	Poor contact of the sensor wires or sensor failed
E6	Poor anti-freeze sensor wire contact or anti-freeze sensor faulty
F0	Manual operation (medium power)
F1	Digital thermometer function
F2	Time programming function
F3	Long resting period
F4	Automatic unit operation (medium power)
CA	When selecting F4, this will appear on the display alternating between the selected temperature
F6	° F Selection
U1	Blower speed 1
U2	Blower speed 2
U3	Blower speed 3
U4	Blower speed 4
U5	Blower speed 5