

## COMPACT 3.0 : CODES ON DISPLAY



DISPLAY	DESCRIPTION *
GL-2	StartUp message: Kit ON
Lb	Low Battery
tc	=Lb /Poor contact in connetions
bb	= Lb
E0	Poor contact of the sensor wires or sensor failed
E2	Condenser fan or blower failure
E6	Poor anti-freeze sensor wire contact or anti-freeze sensor faulty
E9	Compressor protection (cabin tilted)
F0	Manual operation (medium power)
F1	Digital thermometer function
F2	Time programming function
F3	Long resting period
F4	Automatic unit operation (medium power)
CA	When selecting F4, this will appear on the display alternating between the selected temperature
F5	Automatic operation of the unit at maximum power with the engine-off (60 minutes max.)
NP	Not select F5 permitted once the selected time elapsed
F6	° F Selection
U1	Blower speed 1
U2	Blower speed 2
U3	Blower speed 3
U4	Blower speed 4
U5	Blower speed 5
P0	Manual operation/Maximum power
P4	Automatic operation of the unit at maximum power